

NuSCR Manual

(ver. 1.0)

Dependable Software Lab.

KAIST

1 What is NuSCR?

- Nuclear + SCR(Software Cost Reduction)
- Fixed form language for describing requirements
- Suitable for software technology that receives input, performs control logic and gives output
- Suitable for nuclear energy field required technology

2 Background of NuSCR

- Expansion of the ACEL(Wolsong) method
- ACEL(Wolsong)
 - Basic structure : FOD (Function Overview Diagram)
 - Function : SDT (Structured Decision Table) function table
 - History : State node + function
 - Timing : Timing function
- NuSCR
 - Basic structure : FOD
 - Function : 개선된 SDT function table
 - History : Automata
 - Timing : Time Annotated Automata

3 Components of NuSCR

- Input variable
- Output variable
- Function variable
- History variable
- Timed history variable
- FOD (Function Overview Diagram)

4 Variable naming rules







- Add the corresponding prefix to each variable
 - $f_$: function variable
 - $h_$: history variable

- $th_$: timed history variable
- $i_$: input variable
- $o_$: output variable
- $k_$: predefined constant
- $g_$: set of function variable, history variable or timed history variable

5 FOD(Function Overview Diagram)


- A kind of DFD (Data Flow Diagram)
- Describes the relationships between the components of NuSCR
- Display each component with a node
- Display relationships between nodes with one-way arrows
- Use group nodes when composed in classes
- Each node name follows the variable naming rule

5.1 Elements represented in FOD

- Input node, Output node 
- Group node 
- Function node 
- History node 
- Timed history node 
- Data Flow or Transition 


5.2 Example of FOD

g_BP(overview) + External Input/Output



g_BP(detailed) + External Input/Output





6 Function Variable

- Used to describe the system's functional behavior
- Defined with SDT (Structured Decision Table)
 - SDT is a type of Condition/Action table
 - Once the condition is satisfied, the action is performed
 - Familiar table style for the engineer

6.1 SDT(Structured Decision Table)

- Condition
 - Complex condition composed of function variable inputs
 - ie) $k_{X_MIN} \leq f_X \leq k_{X_MAX}$
- Action
 - Assignments for function variables
 - ie) $f_{X_Valid} := 0$

6.2 Examples of SDT

Conditions	1	2
$k_X_MIN \leq f_X \leq k_X_MAX$	T	F
Actions	1	2
$f_X_Valid := 0$	0	
$f_X_Valid := 1$		0

- SDT defines the function Variable f_X_Valid
- Meaning
 - If f_X is greater than or equal to k_X_MIN , and less than or equal to k_X_MAX (condition),
 - Assign 0 to f_X_Valid (action)

6.3 Examples of SDT from RPS items

- Example of function variables defined through SDT



Structured Decision Table:

Conditions	1	2	3
$f_LO_SG1_LEVEL_Val_Out > k_LO_SG1_LEVEL_PV_...$	T	-	F
$f_LO_SG1_LEVEL_Val_Out < k_LO_SG1_LEVEL_PV_...$	-	T	F
Action	1	2	3
$f_LO_SG1_LEVEL_PV_Err := true$	0	0	
$f_LO_SG1_LEVEL_PV_Err := false$			0


7 History Variable

- Used to describe system's condition based action
- Defined with a FSM (Finite State Machine)
 - Components of FSM
 - Finite number of states
 - Transitions between states

7.1 FSM(Finite State Machine)

- State
 - Express each of the system's states
 - ie) A switch has two states : On and Off
- Transition
 - Represents the changes between states
 - Expressed with arrows
 - Each transition has a label
 - label form → Conditions/Actions


7.2 Example of FSM



- FSM that defines the history variable $h_X_OB_Sta$
- Meaning
 - In the initial state NOT_OB_STATE
 - If the conditions $f_X_OB_Perm = 1$ and $f_X_OB_Ini = 1$ are satisfied (condition)
 - Assign the value 1 to $h_X_OB_Sta$ (action)
 - Move to the OB_State (transition)

7.3 Example of FSM from RPS items

- Example of history variables defined through FSM



- Condition : $f_HB_In_t0 < f_HB_In \ \& \ h_HB_Err_Cnt < 1$
- Action : $h_HB_Err_Cnt := 0$


8 Timed History Variable

- Used to describe system's time related actions
- Defined with TTS (Timed Transition System)
 - TTS is an extension of FSM
 - Time Annotated Automata
 - Adds a time restriction to FSM's transition condition
 - Attaches a time restriction in the form of [a,b] in front of the condition

8.1 TTS(Timed Transition System)

- State
 - Describes the systems' different states
- Transition
 - Represents the changes between states
 - Expressed with arrows
 - Every transition has a label
 - label format $\rightarrow [Time_1, Time_2] Conditions/Actions$
 - ie) [1,4]condition=0/action:=1
 - If the condition=0 is maintained for a term of 1~4 hours, assign action=1 and change state


8.2 Example of TTS



- TTS that defines a part of Timed History Variable th_X_Trip
- Meaning
 - In Waiting state
 - For k_Trip_Delay hours (Time Limit)
 - If $f_X \geq k_X_Trip_SetPoint$ and $h_X_OB_Sta = 0$ conditions are satisfied and maintained (condition)
 - Assign th_X_Trip the value 0 (action)
 - Move to the $Trip_By_Logic$ state (transition)

8.3 Example of TTS from RPS items

- Example of Timed History Variable defined through TTS



- **Time duration** : $[k_HI_LOG_POWER_Trip_Dly, k_HI_LOG_POWER_Trip_Dly]$
- **Condition** : $f_HI_LOG_POWER_Val_Out > k_HI_LOG_PWR_Trip_Set$
- **Action** : $th_HI_LOG_PWR_Trip_Logic := true$